# Size: 136x210mm

## 502423

Digital Nose Weight Gauge-Adjustable

### Warning!

**Secure the trailer/caravan against rolling away.**
**Use only on a straight, level surface.**
**Do not use when people are on the trailer / in the caravan, and do not overload, etc.**

**Application:**
Turn the rubberized stand of the drawbar scale outwards to bring it to the same height as the ball head of the car.
Now switch on the drawbar scale in the unloaded state by briefly pressing the on/off button below the display.

Clamp the ball head of the drawbar scale under the drawbar of the trailer/caravan.
Now slowly turn the support wheel up until it has no contact with the ground anymore.
Using the integrated spirit level, check the straight alignment of the drawbar scale and read the measured value.

To switch off the drawbar scale, press and hold the on/off switch for about 2 seconds.
In an unloaded state, the drawbar scale switches off automatically after approx. 1 minute.

**Changing the battery:**
When 'low battery level' is displayed (a low battery or the sign 'lo' is shown), the battery must be changed.

If the battery is low, there is a risk of incorrect measurements.
Open the battery cover with a suitable screwdriver.
Remove the battery and replace it.
Please dispose of empty batteries in the containers provided for this purpose.

**Environmental conditions:**
Do not expose the display to direct sunlight. This can cause damage and/or darkening of the display.

**Functional test**
In order to rule out possible errors due to incorrect storage and/or improper use, a regular check of the measuring accuracy is necessary (at least 1x before first use, once per year or after long periods of non-use).

Bakker Trailer Parts BV
Apolloweg 16
8239 DA Lelystad

BAKKER TRAILERPARTS